
yuwell








Portable phlegm suction unit Model:7E-B5

Quick operation instructions

Assembly











Precautions


- 1. Do not run continuously for more than 30 minutes.
- 2. When adjusting the negative pressure, please block the suction tube to ensure that there is no air leakage in the suction tube (air leakage will affect the adjustment of the negative pressure).
- 3. During use, please make sure that the liquid level in the liquid holder does not exceed the maximum liquid level indication.
- 4. When assembling the lid of the liquid holder to the canister body, make sure that the arrow marks on the surface of the two are aligned, otherwise air leakage may occur or the liquid holder may not be assembled with the main unit.

*For details, please refer to the user's manual

Steps




1.Connect the liquid holder 1 to the main unit 2 (side with interface).



2.Connect the suction tube 4 to the liquid holder 1 and then plug the power cord 5 into the power socket.



3.Block the suction tube **4**, then press the power switch, and regulate vacuum as required through knob.




4. Insert the suction catheter 3 into the suction tube 4.




5.Insert the suction catheter 3 into the desired suction site, then fold and press the indenter on the suction catheter to start suction.



6. After use, turn off the main unit **2** and unplug the suction tube **4**.



7. Press the button and remove the liquid holder 1 away from the main unit 2.



8.Turn the holder lid counterclockwise to separate the lid from the body, and then clean the liquid holder 1.