

## AUTOMATIC HAND DRYER ZONDA (D2500SDB)

**Thank you for purchasing our product. We are sure that it will meet your expectations and maintain a high level of hygiene.**

Electric hand dryer in a housing made of durable and damage resistant materials. The device is equipped with an infrared sensor and a double safety system to prevent overheating.

### Technical specifications:

Rated power:	2500 W
Launch:	automatic
Minimal start distance:	50 – 200 mm
Cable length:	0,9 m
Voltage:	220-240 V
Frequency:	50-60 Hz
Dimensions (H x W x D):	240 x 270 x 142 mm
Housing:	brushed and laquered stainless steel 304
Net Weight:	6,25 kg
Certificate:	CE
Waterproof:	IPX1
Warranty:	24 months

### Mounting:

**Installation of the dryer can perform only person with the current electrical authorization.**

1. Select the installation place (due to regulations), taking into account the cable length and the distance to electrical outlet.
2. Pull the fastening element made of plastic from the dryer housing by strong pull to release the latches.
3. Applying the fastener to the wall, you should set drilling holes for tent pegs.
4. Drill three holes by drill in 6mm diameter, in the drilled holes put attached plugs.
5. Tight the fastener to the wall with screws, which are included in the kit.
6. Slip the hand dryer onto the fastener. Check, by pulling the hand dryer up, whether securing clips blocked the dryer on fastener. Connect plug into the socket.

### Cleaning:

Clean the cover with a soft, damp cloth with a mild, neutral detergents. Do not use abrasive cleaning fluids.

### General notes:

- The dryer must be installed at a height: in places designed for men - 120 cm, women - 115 cm, children - 95 cm, disabled - 100 cm, universal height is 110 cm from the floor.
- Installation of the hand dryer should be made in a way that prevents people using the shower or taking a bath to reach the dryer.
- Do not install the dryer over washbasins. Do not install it above horizontal surfaces within a distance less than 40 cm. Do not install in direct sunlight and over mirror surfaces.
- Install the unit on a solid wall, not exposed to shakes.
- In rooms equipped with baths or shower trays the hand dryer should be installed outside the second zone due to requirements of the standard PN-HD 60364-7-701.
- Do not install in areas with excessive dust, where flammable gases may exist.
- Do not let water or other liquids to get into the dryer.
- For safety purposes, installation and maintenance should be carried out by a person having current electrical authorization.
- Do not block the air inlet and outlet.

**faneco.com**

tel.: +48 61 6100212, fax: +48 61 6100307, info@faneco.com