



KERN & Sohn GmbH

Ziegelei 1

D-72336 Balingen

E-Mail: info@kern-sohn.com

Tel: +49-[0]7433- 9933-0

Fax: +49-[0]7433-9933-149

Internet: www.kern-sohn.com

Zusatzbeschreibung „Justierung“ Additional description “Adjustment”


KERN HGA

Version 1.0
2018-07

Deutsch

English

HGA-ZB-d-1810



KERN HGA

Version 1.0 2018-07

Zusatzbeschreibung „Justierung“

- ⇒ Waage ausschalten
- ⇒ ON/OFF-Taste dreimal drücken, dann ON/OFF-Taste drücken und für 3 sec. gedrückt halten bis „8888“ gefolgt von einer internen Nummer angezeigt wird.
- ⇒ ON/OFF-Taste erneut drücken, „CAL“ gefolgt von “20.00” wird angezeigt.
- ⇒ 20 kg-Justiergewicht anhängen. Nach erfolgter Stillstandskontrolle wird „PASS“ gefolgt vom Gewichtswert des Justiergewichts angezeigt.



KERN HGA

Version 1.0 2018-07

Additional description “Adjustment”

- ⇒ When the scale is power off, press the ON/OFF button for 3 times, then press and hold the button for 3s, till the scale displays 8888, then displays the inner code.
- ⇒ Press the ON/OFF button again, the scale will display “CAL” and “20.00”.
- ⇒ Hanging a 20kg weight on the scale, when the code gets stable, the scale will displays PASS and then displays the calibrated weight. Now the calibration is finished.