

BATHROOM ACCESSORIES

AURA SERIES Double towel rail







Al1311B Black finish

Al1311C Bright finish

Technical Specifications

Main rail thickness

Wall bracket diameter

Wall bracket thickness

Auxiliary bar diameter

Auxiliary bar length

Dimensions

Net weight

AI1311CS Satin finish

4,5 mm

28 mm

1,2 mm

12 mm

540 mm

900 a

600 x28 x 155 mm

General Description

- Bathroom towel rail with double bar, 600 mm in length with double wall fixation and a hidden wall mounting system, made of AISI 304 stainless steel, from Mediclinics' Aura series.
- With an up-to-date design which brings a minimalist and creative touch to your bathroom, this towel rail is ideal for finishing off elegant and modern spaces.
- This double towel rail is very resistant and durable thanks to its high-quality, anti-corrosive and highly resistant stainless steel, and is perfect for ensuring that your bathroom is always tidy and your towels perfectly placed.
- An essential bathroom accessory, this towel rail is ideal for bathrooms in hotels, restaurants, hospitals and nursing homes, as well as for your own home.
- Product suitable for public use.
- Includes stainless steel hardware kit for an easy, convenient and quick installation on brick walls.

Dimensions	
	28mm
15mm	Ø 28mm

Dimensiones: ± 4%

600mm

Components and materials

- Al1311B: double towel rail made of AISI 304 stainless steel black finish
- Al1311C: double towel rail made of AISI 304 stainless steel bright finish.
- Al1311CS: double towel rail made of AISI 304 stainless steel satin finish.
- RAIL: manufactured with 4.5 mm thick AISI 304 stainless steel plate.
- WALL BRACKETS: two units, made with AISI 304 stainless steel cylindrical tube of Ø 28mm and 1.2mm thick. Attached to the bar by means of a threaded stud and nut.
- WALL ANCHORS: two units, made of AISI 304 stainless steel tube of Ø 22mm and 1.0mm thick. Attached to the wall bracket by means of a screw. It has two oval holes (one vertical and one horizontal) to facilitate wall mounting. They always remain hidden from the user's view.

Mediclinics, S.A., reserves the right to make changes and/or modifications to the products and their specifications without prior notice Review 07-20 © mediclinics S.A.

