

## **BATHROOM ACCESSORIES**

AURA SERIES Toilet roll holder



## Al1321B Black finish

# Al1321C Bright finish

## AI1321CS Satin finish

#### **General Description**

- Toilet roll holder without cover, with double wall fixation, made of AISI 304 stainless steel, from Mediclinics' Aura series.
- With an up-to-date, modern and functional design, this toilet roll holder is ideal for both private and public-use bathrooms, in places such as hotels, bars, restaurants, offices, etc.
- The supporting axis for the paper roll has a stopper to prevent the roll from falling off.
- Appropriate for household toilet rolls.
- It has a hidden wall mounting system.
- Includes stainless steel hardware for installation on brick walls.


### Components and materials


- Al1311B: toilet roll holder made of AISI 304 stainless steel black finish.
- Al1311C: toilet roll holder made of AISI 304 stainless steel bright finish.
- Al1311CS: toilet roll holder made of AISI 304 stainless steel satin finish.
- ROLL AXIS: made of 5 mm thick AISI 304 stainless steel sheet.
- WALL BRACKETS: two units, made with AISI 304 stainless steel cylindrical tube of Ø 28mm and 1.2mm thick. Attached to the bar by means of a threaded stud and nut.
- WALL ANCHORS: two units, made of AISI 304 stainless steel tube of Ø 22mm and 1.0mm thick. Attached to the wall bracket by means of a screw. It has two oval holes (one vertical and one horizontal) to facilitate wall mounting. They always remain hidden from the user's view.

#### **Technical Specifications**

Dimensions	238 x28 x 65 mm
Roll axis thickness	5 mm
Wall bracket diameter	28 mm
Wall bracket thickness	1.2 mm
Net weight	400 g

#### **Dimensions**







Dimensions: ± 4%

Mediclinics, S.A., reserves the right to make changes and/or modifications to the products and their specifications without prior notice Review 07-20 © mediclinics S.A.

